

FIGURE 1
(PRIOR ART)




FIGURE 2




Figure 3

400

220

FLASH

BOOT LOADER PROGRAM

0x00400000

DEFAULT
APPLICATION
PROGRAM

0x00000000

FIGURE 4

500




FIGURE 5

FIGURE 6




FIGURE 6

